
## Appendices

### RS232 Commands

RS232 Connector



| Specification |
|---------------|
| N/A           |
| RXD           |
| TXD           |
| DTR           |
| GND           |
| DSR           |
| RTS           |
| CTS           |
| N/A           |
|               |

## **RS232** Protocol Function List

### RS232 Commands

#### RS232 Command Table.

Baud Rate: 9600 Baud Rate: 9600
Data Bits: 8
Parity: None
Stop Bits: 1
Flow Control: None
UART16550 FIFO: Disable
Projector Return (Pass): P
Projector Return (Fail): F Cable type used: Cross over

SEND to projector

XX=01-99, projector's ID, XX=00 is for all projectors

| - 0  | 1 |
|------|---|
| NOTE |   |
|      |   |

Due to the difference application for each model.
Function is dependent on the model purchased.

| 232 ASCII Code        | HEX Code  | Function                                |                       | Description  |
|-----------------------|---|---|-----------------------|--|
| -XX00 1<br>-XX00 0/ 2 | 7E 30 30 30 30 20 31 0D<br>7E 30 30 30 30 20 30/32 0D | Power ON<br>Power OFF                   |                       |  |
| -XX01 1               | 7E 30 30 30 31 20 31 0D                               | Resync                                  |                       |  |
| -XX02 1               | 7E 30 30 30 32 20 31 0D                               | AV Mute                                 | On                    |  |
| -XX02 0/ 2            | 7E 30 30 30 32 20 30/32 0D                            |   | Off                   |  |
| -XX04 1<br>-XX04 2    | 7E 30 30 30 34 20 31 0D<br>7E 30 30 30 34 20 32 0D    | Freeze<br>Unfreeze                      |                       |  |
| -XX04 2<br>-XX11 1    | 7E 30 30 30 34 20 32 0D<br>7E 30 30 31 31 20 31 0D    | IR Function                             | On                    |  |
| -XX11 0/ 2            | 7E 30 30 31 31 20 30/32 0D                            | ne i uncuon                             | Off                   |  |
| -XX12 1               | 7E 30 30 31 32 20 31 0D                               | HDMI                                    |                       |  |
| -XX12 5               | 7E 30 30 31 32 20 35 0D                               | VGA 1                                   |                       |  |
| -XX12 6               | 7E 30 30 31 32 20 36 0D                               | VGA 2                                   |                       |  |
| -XX12 7               | 7E 30 30 31 32 20 37 0D                               | VGA 1 SCART                             |                       |  |
| -XX12 8<br>-XX12 9    | 7E 30 30 31 32 20 38 0D<br>7E 30 30 31 32 20 39 0D    | VGA 1 Component<br>S-video              |                       |  |
| -XX12 9<br>-XX12 10   | 7E 30 30 31 32 20 31 30 0D                            | Video                                   |                       |  |
| -XX12 12              | 7E 30 30 31 32 20 31 32 0D                            | VGA 2 SCART                             |                       |  |
| -XX12 13              | 7E 30 30 31 32 20 31 33 0D                            | VGA 2 Component                         |                       |  |
| -XX20 1               | 7E 30 30 32 30 20 31 0D                               | Display Mode                            | Presentation          |  |
| -XX20 2<br>-XX20 3    | 7E 30 30 32 30 20 32 0D<br>7E 30 30 32 30 20 33 0D    |   | Bright<br>Movie       |  |
| -XX20 3<br>-XX20 4    | 7E 30 30 32 30 20 33 0D<br>7E 30 30 32 30 20 34 0D    |   | sRGB                  |  |
| -XX20 5               | 7E 30 30 32 30 20 35 0D                               |   | User 1                |  |
| -XX20 6               | 7E 30 30 32 30 20 36 0D                               |   | User 2                |  |
| -XX20 7               | 7E 30 30 32 30 20 37 0D                               |   | Blackboard            |  |
| -XX20 8               | 7E 30 30 32 30 20 38 0D                               |   | Classroom             |  |
| -XX21 n               | 7E 30 30 32 31 20 a 0D                                | Brightness                              |                       | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX22 n<br>-XX23 n    | 7E 30 30 32 32 20 a 0D<br>7E 30 30 32 33 20 a 0D      | Contrast                                |                       | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX45 n               | 7E 30 30 32 33 20 a 0D<br>7E 30 30 34 34 20 a 0D      | Sharpness<br>Saturation                 |                       | n= -15 (a=2D 31 35) - +15 (a=31 35)<br>n= -50 (a=2D 35 30) - +50 (a=35 30) |
| -XX44 n               | 7E 30 30 34 35 20 a 0D                                | Tint                                    |                       | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX24 n               | 7E 30 30 32 34 20 a 0D                                | Color                                   | Red Gain              | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX25 n               | 7E 30 30 32 35 20 a 0D                                |   | Green Gain            | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX26 n<br>-XX27 n    | 7E 30 30 32 36 20 a 0D<br>7E 30 30 32 37 20 a 0D      |   | Blue Gain<br>Red Bias | n= -50 (a=2D 35 30) - +50 (a=35 30)<br>n= -50 (a=2D 35 30) - +50 (a=35 30) |
| -XX27 II<br>-XX28 n   | 7E 30 30 32 37 20 a 0D<br>7E 30 30 32 38 20 a 0D      |   | Green Bias            | n= -50 (a=2D 35 30) - +50 (a=35 30)<br>n= -50 (a=2D 35 30) - +50 (a=35 30) |
| -XX29 n               | 7E 30 30 32 39 20 a 0D                                |   | Blue Bias             | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX30 n               | 7E 30 30 33 30 20 a 0D                                |   | Cyan                  | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX31 n               | 7E 30 30 33 31 20 a 0D                                |   | Yellow                | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
| -XX32 n<br>-XX33 1    | 7E 30 30 33 32 20 a 0D<br>7E 30 30 33 33 20 31 0D     |   | Magenta<br>Reset      | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
|                       |   | D :11: (C 1 TM                          |                       | 0 ( 20) 10 ( 2120)   |
| -XX34 n<br>-XX35 1    | 7E 30 30 33 34 20 a 0D<br>7E 30 30 33 35 20 31 0D     | BrilliantColor <sup>TM</sup><br>Degamma | Film                  | n= 0 (a=30) - 10 (a=31 30)   |
| -XX35 1<br>-XX35 2    | 7E 30 30 33 35 20 31 0D<br>7E 30 30 33 35 20 32 0D    | Degamma                                 | Video                 |  |
| -XX35 3               | 7E 30 30 33 35 20 33 0D                               |   | Graphics              |  |
| -XX35 4               | 7E 30 30 33 35 20 34 0D                               |   | PC                    |  |
| -XX36 1               | 7E 30 30 33 36 20 31 0D                               | Colour Temp.                            | Warm                  |  |
| -XX36 2<br>-XX36 3    | 7E 30 30 33 36 20 32 0D<br>7E 30 30 33 36 20 33 0D    |   | Medium<br>Cold        |  |
| -XX37 1               | 7E 30 30 33 37 20 31 0D                               | Colour Space                            | Auto                  |  |
| -XX37 2               | 7E 30 30 33 37 20 32 0D                               | •                                       | RGB                   |  |
| -XX37 3               | 7E 30 30 33 37 20 33 0D                               |   | YUV                   |  |
| -XX39 5               | 7E 30 30 33 39 20 35 0D                               |   | VGA 1                 |  |
| -XX39 9<br>-XX39 10   | 7E 30 30 33 39 20 39 0D<br>7E 30 30 33 39 20 31 30 0D |   | S-Video<br>Video      |  |
| -XX40 1               | 7E 30 30 33 39 20 31 30 0D<br>7E 30 30 34 30 20 31 0D | De-interlace                            | On                    |  |
| -XX40 0/ 2            | 7E 30 30 34 30 20 30/32 0D                            | De interiace                            | Off                   |  |
| -XX60 1               | 7E 30 30 36 30 20 31 0D                               | Format                                  | 4:3                   |  |
| -XX60 1<br>-XX60 2    | 7E 30 30 36 30 20 31 0D<br>7E 30 30 36 30 20 32 0D    | . omiat                                 | 16:9-l                |  |
| -XX60 3               | 7E 30 30 36 30 20 33 0D                               |   | 16:9-ll               |  |
| -XX60 6               | 7E 30 30 36 30 20 35 0D                               |   | Natvie                |  |
| -XX60 7<br>           | 7E 30 30 36 30 20 37 0D                               |   | Auto                  |  |
| -XX61 n               | 7E 30 30 36 31 20 a 0D                                | Overscan                                |                       | n= 0 (a=30) - 10 (a=31 30)   |
| -XX62 n               | 7E 30 30 36 32 20 a 0D                                | Zoom                                    |                       | n= -30 (a=2D 33 30) - +30 (a=33 30)  |
| -XX63 n               | 7E 30 30 36 33 20 a 0D                                | H Image Shift                           |                       | n= -50 (a=2D 35 30) - +50 (a=35 30)  |
|                       |   |   |                       |  |

# Appendices

| ~XX64 n<br>~XX66 n<br>~XX69 1<br>~XX69 0/2  | 7E 30 30 36 34 20 a 0D<br>7E 30 30 36 36 20 a 0D<br>7E 30 30 36 39 20 31 0D<br>7E 30 30 36 39 20 30/32 0D  | V Image Shift<br>V Keystone<br>Auto Keystone           | On<br>Off  | n= -24 (a=2D 32 34) - +24 (a=32 34)<br>n= -30 (a=2D 33 30) - +30 (a=33 30)   |
|---|--|--|--|--|
| -XX70 1 -XX70 2 -XX70 3 -XX70 4 -XX70 5 -XX70 6 -XX70 6 -XX70 7 -XX70 8 -XX70 10 -XX70 11 -XX70 12 -XX70 13 -XX70 14 -XX70 15 -XX70 16 -XX70 17 -XX70 18 -XX70 19 -XX70 20 -XX70 21 | 7E 30 30 37 30 20 31 0D 7E 30 30 37 30 20 32 0D 7E 30 30 37 30 20 33 0D 7E 30 30 37 30 20 33 0D 7E 30 30 37 30 20 33 0D 7E 30 30 37 30 20 34 0D 7E 30 30 37 30 20 36 0D 7E 30 30 37 30 20 36 0D 7E 30 30 37 30 20 36 0D 7E 30 30 37 30 20 39 0D 7E 30 30 37 30 20 31 30 0D 7E 30 30 37 30 20 31 30 0D 7E 30 30 37 30 20 31 30 0D 7E 30 30 37 30 20 31 30 0D 7E 30 30 37 30 20 31 33 0D 7E 30 30 37 30 20 31 33 0D 7E 30 30 37 30 20 31 35 0D 7E 30 30 37 30 20 31 35 0D 7E 30 30 37 30 20 31 35 0D 7E 30 30 37 30 20 31 35 0D 7E 30 30 37 30 20 31 35 0D 7E 30 30 37 30 20 31 38 0D 7E 30 30 37 30 20 31 38 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 31 39 0D 7E 30 30 37 30 20 32 30 0D 7E 30 30 37 30 20 32 30 0D | Language   | English German French Italian Spanish Portuguese Polish Dutch Swedish Norwegian/Danish Finnish Greek Traditional Chinese Simplified Chinese Japanese Korean Russian Hungarian Czechoslovak Arabic Thai |  |
| ~XX71 1<br>~XX71 2<br>~XX71 3<br>~XX71 4  | 7E 30 30 37 31 20 31 0D<br>7E 30 30 37 31 20 32 0D<br>7E 30 30 37 31 20 33 0D<br>7E 30 30 37 31 20 33 0D<br>7E 30 30 37 31 20 34 0D  | Projection   | Front-Desktop<br>Rear-Desktop<br>Front-Ceiling<br>Rear-Ceiling   |  |
| ~XX72 1<br>~XX72 2<br>~XX72 3<br>~XX72 4<br>~XX72 5   | 7E 30 30 37 32 20 31 0D<br>7E 30 30 37 32 20 32 0D<br>7E 30 30 37 32 20 32 0D<br>7E 30 30 37 32 20 33 0D<br>7E 30 30 37 32 20 34 0D<br>7E 30 30 37 32 20 35 0D   | Menu Location  | Top Left Top Right Centre Bottom Left Bottom Right   |  |
| ~XX73 n<br>~XX74 n<br>~XX75 n<br>~XX76 n  | 7E 30 30 37 33 20 a 0D<br>7E 30 30 37 34 20 a 0D<br>7E 30 30 37 35 20 a 0D<br>7E 30 30 37 35 20 a 0D<br>7E 30 30 37 36 20 a 0D   | Signal   | Frequency<br>Phase<br>H. Position<br>V. Position   | n=0 (a=30) - 31 (a=33 31)<br>n=-5 (a=2D 35) - +5 (a=35)<br>n=-5 (a=2D 35) - +5 (a=35)<br>n=-5 (a=2D 35) - +5 (a=35)      |
| ~XX77 n   | 7E 30 30 37 37 20 aabbcc 0D  | Security   | Security Timer   | Hour /Day/ Month n=hh/dd/mm<br>hh= 0 (a=30) ~ 24 (a=32 34)<br>dd= 0 (a=30) ~ 30 (a=33 30)<br>mm= 0 (a=30) ~ 12 (a=31 32) |
| ~XX78 1<br>~XX78 0/ 2   | 7E 30 30 37 38 20 31 0D<br>7E 30 30 37 38 20 30/32 0D  |  | Security Settings  | Enable<br>Disable  |
| ~XX79 n   | 7E 30 30 37 39 20 a 0D   | Projector ID   |  | n=0 (a=30)- 99 (a=39 39)   |
| ~XX80 1<br>~XX80 0/ 2<br>~XX81 n  | 7E 30 30 38 30 20 31 0D<br>7E 30 30 38 30 20 30/32 0D<br>7E 30 30 38 31 20 a 0D  | Audio  | Mute<br>Volume   | On<br>Off<br>n= 0 (a=30) - 10 (a=31 30)  |
| ~XX82 1<br>~XX82 2<br>~XX83 1   | 7E 30 30 38 32 20 31 0D<br>7E 30 30 38 32 20 32 0D<br>7E 30 30 38 33 20 31 0D  | Logo Logo capture                                      | Optoma<br>User   |  |
| ~XX100 1<br>~XX100 0/2<br>~XX101 1<br>~XX101 0/2<br>~XX102 1<br>~XX102 0/2<br>~XX103 1<br>~XX103 0/2  | 7E 30 30 31 30 30 20 31 0D 7E 30 30 31 30 30 20 30/32 0D 7E 30 30 31 30 31 20 31 0D 7E 30 30 31 30 31 20 31 0D 7E 30 30 31 30 31 20 30/32 0D 7E 30 30 31 30 32 20 31 0D 7E 30 30 31 30 32 20 30/32 0D 7E 30 30 31 30 32 20 30/32 0D 7E 30 30 31 30 33 20 31 0D   | Source Lock High Altitude Information Hide Keypad Lock | On Off On Off On Off On Off  | -  |
| ~XX104 1<br>~XX104 2<br>~XX104 2<br>~XX104 2<br>~XX104 2<br>~XX104 2  | 7E 30 30 31 30 34 20 31 0D<br>7E 30 30 31 30 34 20 32 0D<br>7E 30 30 31 30 34 20 33 0D<br>7E 30 30 31 30 34 20 33 0D<br>7E 30 30 31 30 34 20 34 0D<br>7E 30 30 31 30 34 20 35 0D   | Background Colour                                      | Blue<br>Black<br>Red<br>Green<br>White   |  |
| ~XX105 1<br>~XX105 0/ 2<br>~XX106 n   | 7E 30 30 31 30 35 20 31 0D<br>7E 30 30 31 30 35 20 30/32 0D<br>7E 30 30 31 30 36 20 a 0D   | Advanced   | Direct Power On  Auto Power Off (min) Sleep Timer (min)  | On Off n=0 (a=30)-180 (a=31 38 30) (multiple of 5) n=0 (a=30)-995 (a=39 39 35) (multiple of 5)                           |
| ~XX107 n<br>~XX114 1<br>~XX114 0/ 2   | 7E 30 30 31 30 37 20 a 0D<br>7E 30 30 31 31 34 20 31 0D<br>7E 30 30 31 31 34 20 30/32 0D   |  | ECO Standby (<1W)<br>ECO Standby (<1W)   | On<br>Off  |
| ~XX107 n<br>~XX114 1  | 7E 30 30 31 31 34 20 31 0D   | Lamp Setting   |  |  |

# Appendices

| ~XX112 0/ 2  | 7E 30 30 31 31 32 20 30/32 0D | No                          |  |
|--------------|-------------------------------|-----------------------------|--|
| SEND to Remo | te                            |                             |  |
| ~XX140 1     | 7E 30 30 31 34 30 20 31 0D    | Power                       |  |
| ~XX140 3     | 7E 30 30 31 34 30 20 33 0D    | Remote Mouse Up             |  |
| ~XX140 4     | 7E 30 30 31 34 30 20 34 0D    | Remote Mouse Left           |  |
| ~XX140 5     | 7E 30 30 31 34 30 20 35 0D    | Remote Mouse Enter          |  |
| ~XX140 6     | 7E 30 30 31 34 30 20 36 0D    | Remote Mouse Right          |  |
| ~XX140 7     | 7E 30 30 31 34 30 20 37 0D    | Remote Mouse Down           |  |
| ~XX140 8     | 7E 30 30 31 34 30 20 38 0D    | Mouse Left Click            |  |
| ~XX140 9     | 7E 30 30 31 34 30 20 39 0D    | Mouse Right Click           |  |
| ~XX140 10    | 7E 30 30 31 34 30 20 31 30 0D | Up/Page +                   |  |
| ~XX140 11    | 7E 30 30 31 34 30 20 31 31 0D | Left/Source                 |  |
| ~XX140 12    | 7E 30 30 31 34 30 20 31 32 0D | Enter (for projection MENU) |  |
| ~XX140 13    | 7E 30 30 31 34 30 20 31 33 0D | Right/Re-SYNC               |  |
| ~XX140 14    | 7E 30 30 31 34 30 20 31 34 0D | Down/Page -                 |  |
| ~XX140 15    | 7E 30 30 31 34 30 20 31 35 0D | Keystone +                  |  |
| ~XX140 16    | 7E 30 30 31 34 30 20 31 36 0D | Keystone -                  |  |
| ~XX140 17    | 7E 30 30 31 34 30 20 31 37 0D | Volume -                    |  |
| ~XX140 18    | 7E 30 30 31 34 30 20 31 38 0D | Volume +                    |  |
| ~XX140 19    | 7E 30 30 31 34 30 20 31 39 0D | Brightness                  |  |
| ~XX140 20    | 7E 30 30 31 34 30 20 32 30 0D | Menu                        |  |
| ~XX140 21    | 7E 30 30 31 34 30 20 32 31 0D | Zoom                        |  |
| ~XX140 22    | 7E 30 30 31 34 30 20 32 32 0D | Contrast                    |  |
| ~XX140 23    | 7E 30 30 31 34 30 20 32 33 0D | Freeze                      |  |
| ~XX140 24    | 7E 30 30 31 34 30 20 32 34 0D | AV Mute                     |  |
| ~XX140 25    | 7E 30 30 31 34 30 20 32 35 0D | S-Video                     |  |
| ~XX140 26    | 7E 30 30 31 34 30 20 32 36 0D | VGA                         |  |
| ~XX140 27    | 7E 30 30 31 34 30 20 32 37 0D | Video                       |  |

### SEND from projector automatically

| 232 ASCII Code                         | HEX Code                             | Function | Projector Return | Description                                  |             |
|--|--------------------------------------|----------|------------------|--|-------------|
| when got invalid c<br>when standby/war | command<br>ming/cooling/out of range |          | NG<br>INFOn      | n: 0/1/2/3 = Standby / Warming / Cooling / O | ut of Range |

#### READ from projector

| 232 ASCII Code | HEX Code                   | Function          | Projector Return | Description  |
|----------------|----------------------------|-------------------|------------------|--|
| ~XX121 1       | 7E 30 30 31 32 31 20 31 0D | Input Source      | OKn              | n: 0/2/4/5= None/VGA/S-Video/Video   |
| ~XX122 1       | 7E 30 30 31 32 32 20 31 0D | Software Version  | OKaaaa           |  |
| ~XX123 1       | 7E 30 30 31 32 33 20 31 0D | Display Mode      | OKn              | n: 0/1/2/3/4/5=Presentation/Bright/Movie/s   |
| ~XX124 1       | 7E 30 30 31 32 34 20 31 0D | Power State       | OKn              | n: 0/1=off/on  |
| ~XX125 1       | 7E 30 30 31 32 35 20 31 0D | Brightness        | OKn              |  |
| ~XX126 1       | 7E 30 30 31 32 36 20 31 0D | Contrast          | OKn              |  |
| ~XX127 1       | 7E 30 30 31 32 37 20 31 0D | Aspect Ratio      | OKn              | n: 0/1/2/4/7=4:3/16:9I/16:9II/Native/auto  |
| ~XX128 1       | 7E 30 30 31 32 38 20 31 0D | Color Temperature | OKn              | n: 0/1/2=Warm/Medium/cold  |
| ~XX129 1       | 7E 30 30 31 32 39 20 31 0D | Projection Mode   | OKn              | n: 0/1/2/3=Front-Desktop/Rear-Desktop/Front-Desktop/Front-Desktop/Rear-Desktop/Front-D |
| ~XX150 1       | 7E 30 30 31 35 30 20 31 0D | Information       | OKabbbbcdddde    | a: 1/0=On/Off  |
|                |                            |                   |                  | bbbb: Lamp Hour  |
|                |                            |                   |                  | c: source 0/2/4/5= None/VGA/S-Video/Vid  |
|                |                            |                   |                  | dddd: FW version   |
|                |                            |                   |                  | e: Display mode 0/1/2/3/4/5=Presentation/  |
| ~XX151 1       | 7E 30 30 31 35 31 20 31 0D | Model Name        | OKn              | n: 1/2/3/4=ES520/EX530/EX520/EX530   |
| ~XX152 1       | 7E 30 30 31 35 32 20 31 0D | RS232 Version No  | OKn              |  |